



The pre-drilled hole must be vacuumed out prior to the epoxy application.
 The epoxy anchor adhesive must be allowed to cure prior to primer application.
 The anchor bolt must be mechanically abraded where it is to be in contact with the primer.

Gaco Western

TITLE

Anchors w/Epoxy Adhesive

SIZE

A4

CAGE CODE

DWG NO

DW-AEA-01

REV

SCALE

SHEET