



The metal must be solvent wiped prior to primer application to remove any oil residue.

The N-1207 adhesive must be applied to the metal, the concrete and the back of the NF-621.

The NF-621 Neoprene sheet must be solvent wiped prior to the U-5677 primer application.

Both the E-5320 and the LM-60 must extend over the ends of the neoprene sheet.

				Gaco Western			
				TITLE			
				Overflow Scupper			
				TITLE			
SIZE		CAGE CODE		DWG NO		REV	
A4				GWSP-OS-01			
3-14-2012				SCALE		Nils Nedrelid SHEET	