



All areas of the pipe and insulation that will have contact with the adhesive must be primed with GacoFlex E-5320.

The neoprene sheet must be set in wet LM-60 where it is not glued.

Gaco Western			
TITLE			
Pipe Penetration w/Form Filler			
SIZE	CAGE CODE	DWG NO	REV
A4		GWSP-PPFF-01.1	
SCALE			SHEET