



- Lock Nut
- SS Plate Support
- Approved Protection Board
- GacoFlex E-5320 Primer
- LM-60, 90 mils (dry)
- Torque Nut
- Mechanical Anchor

It is necessary to install a torque nut to prevent the seal between the LM-60 and the anchor from being disturbed during installation. The torque nut must be installed in an inverted sealant pocket, covered w/min 1/2" LM-60.

The steel rod needs to be mechanically abraded and primed with GacoFlex E-5320 Primer where there is contact with the GacoFlex LM-60!

Gaco Western			
TITLE			
Mechanical Anchor w/Inverted Sealant Pan			
SIZE	CAGE CODE	DWG NO	REV
A4		GWSP-MAISP-01	
SCALE	SHEET		